



Edge Joining Foot

Stitch: Zigzag

Width: Pre-set

Length: Pre-set

Tension: Pre-set

Fabric, needles, notions required:

Edging or insertion lace; fine fabrics such as batiste, silk or linen; universal needle, size 70/10; rayon or heirloom embroidery thread for needle and bobbin; spray starch

heirloom — attaching lace to fabric

Attach lace to fabric using this easy French hand-sewing by machine technique.

1. Prepare the fabric and lace with spray starch. With right sides together, place the lace on top of the fabric with the fabric extending approximately 1/8" beyond. Position the fabric and lace to the left of the blade on the edge joining foot with the blade on top of the edge of fabric.



If your machine has a right sided zigzag, select that stitch. Otherwise adjust the zigzag width so the right needle swing falls off the edge of the fabric and the left falls into the header of the lace. The fabric will roll over the edge of the lace as you sew. (#1)

Another method you can use to attach lace to fabric is to first prepare the edge of the fabric by using the rolled and whipped edge technique.

Place the rolled edge on one side of the metal blade on the foot and the lace on the other. Zigzag the two pieces together.