






Assembly Instructions





IMPORTANT: Please read these instructions before assembling!







Dixie Cutting Table Page 3 Assembly Instructions



Step 1. Slide in adjustable legs (L) into frame legs support (F1) to desired height and lock using bolts


(b1) with (r1) Allen key spanner as shown on the illustration below.






Dixie Cutting Table Page 4 Assembly Instructions

Step 3. Connect the two frame leg supports (F1) with three rails (R) using bolts (b2) using Allen key spanner (r2) as shown on the illustration below.




Step 4. Connect the two side leg supports (S) with leg frame assembly (F1) using bolts (b2) with Allen key spanner (r2) as shown on the

Place the Fixed shelf (F) on the place and attach using bolts (b4) using Allen key spanner (r1)firmly as shown on the illustration below.




Dixie Cutting Table Page 5 Assembly Instructions




Step 7. Attach plastic support tube (p) with connector (b) using bolt (b3) firmly as shown on the illustration below.


b3 4x8 Bolt **x2**

Step 8. Attach plastic support tube (p) and connector (b) assembly with screws (s1) firmly on both sides (A1) following the predrilled holes as shown on the illustration below.




Dixie Cutting Table Page 7 Assembly Instructions





Wood Parts and Part Numbers								
Ref.	Description	Part#						
	Cabinet Model#	3401 (White)						
Α	Top Panel	3401PARTA						
A1	Leaf Panel	3401A1						
F	Fixed Shelf	3401F						
F1	Frame Leg Support	3401F1						
S	Side Leg Support	3401S						
L	Adjustable Leg with Caster	3401L						
R	Rail	3401R						
				-				

Hardware Included with Part Numbers



Item	Description	Part No.
B1	6x12 Bolt	3401B1
B2	8x25 Bolt	3401B2
В3	4x8 Bolt	3401B3
В4	6x35 Bolt	3401B4
В	Bracket	3401B
Р	Plastic Support Tube	3401P
H1	Hinge	3401H1
R1	4mm Allen Key	3401R1
R2	5mm Allen Key	3401R2
R3	14mm Spanner	3401R3
S1	3.5x14 Screw	3401S1
Т	Caster	3401T




Accessories to Complete Your Sewing Experience

Custom Insert

Enhance your sewing experience with a custommade insert for your Arrow or Kangaroo cabinet. Inserts are designed to reduce the gap between the machine and cabinet opening. This provides an ergonomic work surface for the free arm of the sewing machine, allowing for straighter stitches, less fatigue and an overall better experience using your machine and cabinet.

Arrow Sewing Chairs

Our adjustable height sewing chair is a perfect accessory for any craft and sewing room. The chair's height is adjustable with easy to use controls and the cushions provide perfect lumbar support and comfort for those long sewing hours. Chair features five casters on a star base for greater movement at your sewing cabinet or crafting surface. Lift the seat cushion to reveal a hidden storage compartment for your small notions or patterns.





Hydraulic Sewing Chair

P.O. Box 307 Delavan, WI 53115 1-800-533-7347 Ext. 1 cs@arrowcabinets.com www.arrowcabinets.com