



IDEAL FOR EVERYDAY SEWING AND MENDING

Beginners Will Love the Ease of Use and Affordability

- **Built-in Stitches and Buttonholes**
17 built-in sewing stitches, including 1 style of four-step buttonhole.
- **Easy-to-Use Blind Hem Stitch**
Stitch professional-looking hems, which helps make mending less of a chore.
- **Brightly Lit LED Work Area**
Easy on the eyes when sewing on dark fabrics, ensuring accurate seams and stitch quality.
- **Easy Bobbin Winding System**
Winds the bobbin when pressing on the vertical shaft.
- **Stitch Selector Dial**
Choose the desired pattern from the reference guide, and then easily select your choice using the convenient dial.
- **Upper Thread Tension Control Dial**
Controls thread tension to create even stitches.
- **Free Arm Sewing Surface**
Perfect for sewing cuffs and sleeves.
- **Adjustable Pattern Selection and Upper Thread Tension Control**
Adjust the convenient dials to select your pattern and thread tension.
- **Jam-Resistant Drop-in Top Bobbin**
Just drop in a full bobbin, pull the thread through the slot, and start sewing.

Basic Features

LCD Display Size (Horizontal x Vertical) Inches	—
Display (Number of Colors)	—
Stitch Select	Dial
Screensaver	—
Opening Screen	—
On-Screen Help	—
Built-in Languages	—
On-Screen Editing	—
Lighting	1 LED
Thread Tension	Manual
Needle Threading System	—
Easy Bobbin Winding	•
Adjustable Bobbin Winding Speed	—
Thread Sensor	—
Thread Sensor On/Off	—
Automatic Thread Cutter	—
Quick-Set Bobbin	—
Full USB	—
Computer Connectivity with Update Capability	—
Mouse Capability by USB	—
Media Type	—

Sewing Features

Bed Area (Depth x Width) Inches	4.6 x 8.5
Work Space (Height x Width) Inches	3.8 x 6.2
Maximum Sewing Speed (Stitches Per Minute)	800
Knee Lifter	—
Feed Dog	6
Back to Beginning Key	—
Standard Presser Feet Included with Machine	4
Built-in Sewing Stitches (Includes Buttonhole Styles)	17
Buttonhole Styles	1 Four-Step
Built-in Sewing Lettering Fonts	—
Stitch Width	5mm
Stitch Length	4mm
My Custom Stitch Feature	—
Side Feeding	—
Start/Stop Button	—
Speed Controller	—
Twin Needle Setting Key	—
Needle Position Key (Up/Down)	—

PACESETTER PS100 SEWING

Included Accessories

- Zigzag Foot (XC4901021)
- Buttonhole Foot (X59369321)
- Zipper Foot (XE9369001)
- Button Sewing Foot (XE2137001)
- Feed Dog Cover (XC6063021)
- Foot Controller (XC7359021)
- Additional Accessories Included in Box

Recommended Optional Accessories*

- Non-Stick Foot (SA114)
- Fringe Foot (SA142)
- Walking Foot (SA107)
- Quilting Foot (SA129)
- 1/4" Quilting Foot (SA125)
- Narrow Hemmer Foot (SA127)
- Blind Stitch Foot (SA134)
- Quilting Guide (SA132)
- Additional Optional Accessories Available for Purchase

Machine Specifications

UPC: 0125026556364

Weight: 11.46 lbs.

Footprint: 15.31" L x 5.87" W x 12.01" H

*Additional purchase required.

For more information, visit www.brothersews.com
or call 1-800-4-A-BROTHER

     /brothersews

brother
at your side

KEY: • Feature Included — Feature Not Included

All specifications subject to change without prior notice.