

OPERATION INSTRUCTIONS

SET THE TIMER:

Press the **TIMER BUTTON** until the desired number of hours is represented by Green LEDs (one LED for each hour).

CONTINUOUS OPERATION:

For tough items like hockey or football pads, run pureAir SPORT continuously inside your bag by leaving the power on and the unit connected to a USB power source.

Please review the Owner's Manual for other important information.



SPORT

QUICKSTART GUIDE


TURN ON:

Hold the **POWER BUTTON** until it beeps and the LEDs turn GREEN.

DEFAULT RUN TIME: 1 HOUR

TURN OFF:

Hold the **POWER BUTTON** until it beeps. The fan will continue to run and Blue LEDs will flash for fifteen seconds while pureAir SPORT turns OFF.



CHARGING INFORMATION

CHECK THE BATTERY:

Press the **POWER BUTTON** for less than one second to view the current charge. Each Solid Blue LED represents 25%, and all 4 Solid Blue LEDs represents a full charge.

CHARGE THE BATTERY:

Connect to a USB Outlet until the 1-4 Flashing Blue LEDs change to 4 Solid Blue LEDs.

Please review the Owner's Manual for other important information.

