


Parts List

MO-80CB



JUKI

No.H001-03


パーツリストご利用に際して

1. 仕向け地によって使用部品が異なることがあります。
仕向け地別の欄を参照してください。
仕向け地についてはカートンケースのバーコードラベルを確認してください。
2. 仕向け地毎の電圧例を記載します。
電圧はミシンの定格銘版に記載されています。
CE、CH、SAA: 220～240V
UL: 120V
JP: 100V
3. 単品で注文できない部品があります。

HOW TO MAKE USE OF THIS PARTS LIST


1. The parts used may vary depending on the specifications.
Refer to column "by specification".
Check the carton case barcode label for specifications.
2. A voltage example for each specification is shown.
The voltage is indicated on the rating label of the sewing machine.
CE、CH、SAA: 220-240V
UL: 120V
JP: 100V
3. Some parts cannot be ordered separately.

1. Front cover / Lamp cover




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	1	1	Front cover	
—	1	2	Thread guide (C)	
—	1	3	Thread guide (B)	
—	1	4	Thread guide (C)	
—	1	5	Thread guide (A)	
—	1	6	Shielding plate	
—	1	7	Thread take-up cover	
—	1	8	Lamp cover	
—	1	9	Knife holder	
—	1	10	Thread cutting	
—	1	11	Screw cap	
—	1	12	Sticker	
—	1	13	Needle sticker (CE/CH)	CE/CH
—	1	14	Warning sticker (JP)	JP
—	1	15	Set screw	
—	1	16	Set screw	
—	1	17	Washer	
—	1	18	Front cover set (No. 1.2.3.4.5.6.7.12 included)	UL/ CE/CH
—	1	19	Front cover set (No. 1.2.3.4.5.6.7.12.14 included)	JP
—	1	20	Lamp cover set (No. 8.9.10 included)	UL/JP
—	1	21	Lamp cover set (No. 8.9.10.13 included)	CE/CH

2. Tension dial / Auto release




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	2	1	Tension dial holder	
—	2	2	Release plate	
—	2	3	Restoring spring	
—	2	4	Tension dial holder set	
—	2	5	Tension disc	
—	2	6	Tension disc	
—	2	7	Tension spring (Left needle)	
—	2	7	Tension spring (Right needle and Upper looper)	
—	2	7	Tension spring (Lower looper)	
—	2	8	Tension regulate nut	
—	2	9	Tension regulate pin (White)	
—	2	10	Tension regulate disc (White)	
—	2	11	Tension dial	
—	2	12	Tension dial	
—	2	13	Tension dial setting plate	
—	2	14	Set screw	
—	2	15	Set screw	
—	2	16	Set screw	
—	2	17	Washer	
—	2	18	Washer	
—	2	19	Tension dial set (Left needle) (No. 4.5.6.7.8.9.10.11.13.14.17.18 included)	
—	2	20	Tension dial set (Right needle/Upper looper) (No. 4.5.6.7.8.9.10.11.13.14.17.18 included)	
—	2	21	Tension dial set (Lower looper) (No. 4.5.6.7.8.9.10.12.13.14.17.18 included)	
—	2	22	Tension dial holder set (No. 1.2.3.15.19.20.21.22 included)	

3. Looper cover / Base plate




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	3	1	Looper cover	
—	3	2	Looper cover accessories holder	
—	3	3	Looper cover hinge shaft	
—	3	4	Looper cover hinge spring	
—	3	5	Looper cover hinge	
—	3	6	Looper cover regulate holder	
—	3	7	Base plate	
—	3	8	Spring	
—	3	9	Micro switch contactor	
—	3	10	Rubber	
40233656	3	11	Micro switch	
—	3	12	E ring	
—	3	13	Set screw	
—	3	14	Set screw	
—	3	15	Set screw	
—	3	16	Set screw	
—	3	17	Washer	
—	3	18	Washer	
—	3	19	Looper cover set (No. 1.3.4.5.6.12.15 included)	
—	3	20	Base plate set (No. 7.8.9.11.14 included)	

4. Side cover / Extension table / Back cover / Thread guide bar / Spool stand




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	4	1	Back cover	
—	4	2	Tension guide A cover	
40233721	4	3	Spring	
—	4	4	Thread guide A	
—	4	5	Thread guide A	
—	4	6	Thread guide A spring	
—	4	7	Thread guide A spring holder	
—	4	8	Spool stand	
40233657	4	9	Threading guide	
40233658	4	10	Extension bar	
—	4	11	Extension bar setting	
—	4	12	Spool holder	
—	4	13	Extension table	
—	4	14	Attached extension table	
—	4	15	Attached extension table attached plate	
—	4	16	Side cover	
—	4	17	Screw cap	
—	4	18	Warning label(CE/CH)	CE/CH
—	4	19	Set screw	
—	4	20	Set screw	
—	4	21	Set screw	
—	4	22	Washer	
—	4	23	Washer	
—	4	24	Back cover set (No. 1.2.4.5.6.7 included)	
40233659	4	25	Thread guides set (No. 9.10.11.21.23 included)	
—	4	26	Attached extension table set (No. 14.15 included)	

5. Machine frame / Lower cutter / Stitch plate




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	5	1	Machine frame	
—	5	2	Bushing	
—	5	3	Bushing	
—	5	4	Bushing	
—	5	5	Bushing	
—	5	6	Bushing	
—	5	7	Bushing	
40233693	5	8	Bushing	
—	5	9	Bushing	
—	5	10	Lower cutter holder	
—	5	11	Lower cutter regulate screw	
—	5	12	Cutting width knob	
—	5	13	Lower cutter holder shaft	
—	5	14	Slide holder located shaft	
—	5	15	Lower cutter holder spring	
—	5	16	Upper knife set cover	
40233660	5	17	Lower knife	
40233661	5	18	Needle plate	
40233662	5	19	Fixed lever	
—	5	20	Fixed board	
40233663	5	21	Moving lever	
—	5	22	Moving lever slide holder	
—	5	23	Moving lever cover	
—	5	24	Stitch plate setting board	
—	5	25	Front feed dog guide board	
—	5	26	Led holder B	
40233664	5	27	LED PCB set (220~240V)	CE/CH
40233665	5	27	LED PCB set (100~120V)	UL/JP
40233666	5	28	Set screw	
—	5	29	E ring	
—	5	30	E ring	
40233667	5	31	Set screw	
—	5	32	Set screw	
—	5	33	Set screw	
—	5	34	Set screw	
—	5	35	Set screw	
—	5	36	Set screw	
—	5	37	Set screw	
—	5	38	Set screw	

5. Machine frame / Lower cutter / Stitch plate




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	5	39	Set screw	
—	5	40	Washer	
—	5	41	Washer	
—	5	42	Washer	
40233668	5	43	Stitch plate set (No. 18.19.20.21.22.31 included)	
—	5	44	Lower cutter holder (No. 10.11 included)	

6. Main shaft / Upper knife




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	6	1	Main shaft	
—	6	2	Hand wheel	
—	6	3	Hand wheel cap	
40186418	6	4	Feed driving lever	
40233670	6	5	Feed cam	
—	6	6	Bushing	
—	6	7	Setting collar	
40131212	6	8	Looper cam (A)	
40233672	6	9	Needle bar cam	
40233673	6	10	Upper cutter cam	
40233674	6	11	Lower looper cam	
40131338	6	12	Feed dog supporter slide block	
40233676	6	13	Feed dog cam	
—	6	14	Bushing	
—	6	15	Needle bar link	
—	6	16	Needle bar link pin	
40233677	6	17	Fork	
—	6	18	Bushing	
—	6	19	Upper knife shaft	
—	6	20	Upper knife arm	
—	6	21	Upper knife holder collar	
—	6	22	Upper knife spring	
—	6	23	Upper knife holder	
—	6	24	Upper knife	
40233678	6	25	Upper looper shake link	
40131191	6	26	Bearing	
—	6	27	Looper shaft link	
—	6	28	Bushing	
40233680	6	29	Upper looper shaft	
40233681	6	30	Lower looper link (B)	
40233682	6	31	Lower looper shaft	
—	6	32	Bushing	
—	6	33	Pin	
—	6	34	Inverted retaining ring	
—	6	35	E ring	
—	6	36	E ring	
—	6	37	Set screw	
—	6	38	Set screw	
—	6	39	Set screw	

6. Main shaft / Upper knife




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	6	40	Set screw	
—	6	41	Set screw	
—	6	42	Set screw	
—	6	43	Set screw	
—	6	44	Set screw	
—	6	45	Set screw	
—	6	46	Washer	
—	6	47	Washer	
—	6	48	Washer	
—	6	49	Washer	
—	6	50	Washer	
—	6	51	Washer	
—	6	52	Washer	
—	6	53	Washer	
—	6	54	Washer	
—	6	55	Feed driving lever set (No. 4.38 included)	
—	6	56	Feed cam set (No. 5.38 included)	
—	6	57	Setting collar set (No. 7.37 included)	
—	6	58	Looper cam (A) set (No. 8.38 included)	
—	6	59	Needle bar cam set (No. 9.38 included)	
—	6	60	Upper cutter cam set (No. 10.38 included)	
—	6	61	Lower looper cam set (No. 11.38 included)	
—	6	62	Feed dog cam set (No. 13.38 included)	
—	6	63	Fork set (No. 17.44.45 included)	
—	6	64	Upper knife shaft set (No. 19.20.41.42.46 included)	
—	6	65	Upper knife holder collar set (No. 21.39 included)	
—	6	66	Upper looper shake link set (No. 25.38 included)	
—	6	67	Looper shaft link set (No. 27.42 included)	
—	6	68	Lower looper link (B) set (No. 30.38 included)	

7. Needle bar connecting arm




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	7	1	Needle bar drive link shaft	
—	7	2	Needle bar link	
—	7	3	Needle bar link pin	
40233683	7	4	Needle bar drive link	
40233684	7	5	Needle bar connecting arm	
—	7	6	Feed drive link pin (B)	
40233694	7	7	Needle bar setting link	
—	7	8	Setting collar	
—	7	9	Needle bar thread take-up lever	
—	7	10	E ring	
—	7	11	Set screw	
—	7	12	Set screw	
—	7	13	Set screw	
—	7	14	Set screw	
—	7	15	Washer	
—	7	16	Washer	
—	7	17	Washer	
—	7	18	Needle bar drive link set (No. 4.13 included)	
—	7	19	Needle bar setting link set (No. 7.14 included)	
—	7	20	Setting collar set (No. 8.12 included)	

8. Stitch length dial / Handle




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	8	1	Handle	
—	8	2	Handle supporter (R)	
—	8	3	Handle supporter pin	
—	8	4	Needle bar locate support set	
—	8	5	Feed regulate holder	
—	8	6	Stitch length dial	
—	8	7	Differential feed dial	
—	8	8	Spring	
—	8	9	Feed regulate cam	
—	8	10	Feed regulate link set	
—	8	11	Feed driving lever pin	
40233685	8	12	Feed slide holder	
—	8	13	Bushing	
—	8	14	Feed regulate holder shaft	
40131249	8	15	Feed slide block	
40186418	8	16	Feed driving lever	
—	8	17	Feed shake link	
—	8	18	Feed dog holder pin	
—	8	19	Feed shake link pin	
—	8	20	Feed link	
—	8	21	Bushing	
—	8	22	Differential feed regulator link A set	
—	8	23	Differential feed regulate cam	
—	8	24	Differential feed regulated shaft	
—	8	25	Differential feed regulated link (B)	
—	8	26	Setting collar	
—	8	27	Differential feed regulated holder	
40233688	8	28	Differential feed slide block	
—	8	29	Looper shaft link pin	
—	8	30	E ring	
—	8	31	E ring	
—	8	32	E ring	
—	8	33	E ring	
—	8	34	Set screw	
—	8	35	Set screw	
—	8	36	Set screw	
—	8	37	Set screw	
—	8	38	Set screw	
—	8	39	Set screw	

8. Stitch length dial / Handle




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	8	40	Set screw	
—	8	41	Set screw	
—	8	42	Washer	
—	8	43	Washer	
—	8	44	Washer	
—	8	45	Washer	
—	8	46	Washer	
—	8	47	Washer	
—	8	48	Washer	
—	8	49	Washer	
—	8	50	Feed regulate cam set (No. 9.40 included)	
—	8	51	Feed slide holder set (No.12.37 included)	
—	8	52	Feed driving lever set (No.16.37 included)	
—	8	53	Feed link set (No.20.37.41.44 included)	
—	8	54	Differential feed regulate cam set (No.23.39 included)	
—	8	55	Setting collar set (No.26.35 included)	
—	8	56	Differential feed regulated holder set (No.27.37.40.43 included)	

9. Feed dog




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	9	1	Feed dog movement link shaft	
—	9	2	Bushing	
—	9	3	Setting collar	
—	9	4	Bushing	
—	9	5	Feed dog shake link	
—	9	6	Feed dog holder	
—	9	7	Feed dog shaft	
—	9	8	Eccentric pin	
—	9	9	Feed dog driving lever	
—	9	10	Spring	
—	9	11	Spring	
40233689	9	12	Feed dog (front)	
—	9	13	Spring	
40233690	9	14	Feed dog (rear)	
40233691	9	15	Differential feed slide holder	
—	9	16	Differential feed link	
—	9	17	Differential feed link pin	
—	9	18	Differential feed link pin	
—	9	19	Pin	
—	9	20	E ring	
—	9	21	E ring	
—	9	22	E ring	
—	9	23	Set screw	
—	9	24	Set screw	
—	9	25	Set screw	
—	9	26	Set screw	
—	9	27	Washer	
—	9	28	Washer	
—	9	29	Washer	
—	9	30	Washer	
—	9	31	Washer	
—	9	32	Setting collar set (No. 3.25 included)	
—	9	33	Feed dog shake link set (No. 5.24.26 included)	
—	9	34	Feed dog driving lever set (No. 9.25 included)	
—	9	35	Differential feed slide holder set (No. 15.26 included)	

10. Needle bar / Presser bar / Presser foot




JUKI品番 JUKI parts No.	分類 Class	No	品名 (英) parts name	仕向地別 by specification
40131282	10	1	Needle bar	
40233693	10	2	Bushing	
40233694	10	3	Needle bar setting link	
-	10	4	Needle clamp nut	
40131283	10	5	Needle clamp	
40131284	10	6	Needle clamp thread guide	
-	10	7	Needle	
-	10	8	Presser bar	
-	10	9	Presser bar setting link	
-	10	10	Spring	
-	10	11	Presser bar regulate screw	
-	10	12	Presser foot lifter holder set	
40233697	10	13	Presser bar lifter	
-	10	14	Release press board	
-	10	15	Needle bar locate support set	
-	10	16	LED holder	
-	10	17	LED cover	
40233664	10	18	LED PCB set (220~240V)	CE/CH
40233665	10	18	LED PCB set (100~120V)	UL/JP
40131300	10	19	Presser foot holder	
40233699	10	20	Presser foot	
-	10	21	Spring	
40233700	10	22	Presser foot set (No. 20.21.22 included)	
-	10	23	Set screw	
-	10	24	E ring	
-	10	25	E ring	
-	10	26	Set screw	
40131285	10	27	Set screw	
-	10	28	Set screw	
-	10	29	Set screw	
-	10	30	Set screw	
-	10	31	Set screw	
-	10	32	Set screw	
-	10	33	Washer	
-	10	34	Washer	
-	10	35	Washer	
40131308	10	36	Needle bar set (No. 1.2.4.5.6.26.27.28 included)	
-	10	37	Needle bar set (No. 1.2.3.4.5.6.7.26.27.28 included)	
-	10	38	Needle bar setting link set (No. 3.32 included)	
-	10	39	Presser bar setting link set (No. 9.29 included)	

11. Upper looper




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	11	1	Upper looper connecting arm	
—	11	2	Lower looper thread take-up lever	
—	11	3	Color sticker (red)	
—	11	4	Color sticker (blue)	
40233703	11	5	Slide shaft	
40233704	11	6	Slide shaft pin	
—	11	7	Slide shaft holder pin	
40233705	11	8	Slide shaft holder	
40233706	11	9	Upper looper threading guide	
40233707	11	10	Upper looper	
40233719	11	11	2-thread converter	
—	11	12	Set screw	
—	11	13	Set screw	
—	11	14	Set screw	
—	11	15	Set screw	
—	11	16	Washer	
—	11	17	Washer	
—	11	18	Washer	
—	11	19	Washer	
—	11	20	Upper looper connecting arm set (No. 1.14 included)	
—	11	21	Lower looper thread take-up lever set (No. 2.3.4 included)	

12. Lower looper



JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
—	12	1	Lower looper supporter	
40233708	12	2	Lower looper protect board	
40233709	12	3	Lower looper	
—	12	4	Auto threader	
—	12	5	Auto threader shaft	
—	12	6	Auto threader spring	
—	12	7	Lower looper thread guide	
—	12	8	Color sticker (blue)	
—	12	9	Color sticker (red)	
—	12	10	Washer	
—	12	11	Nut	
—	12	12	E ring	
—	12	13	Set screw	
—	12	14	Set screw	
—	12	15	Set screw	
—	12	16	Washer	
—	12	17	Washer	
—	12	18	Washer	
—	12	19	Lower looper supporter set (No. 1.15.18 included)	
—	12	20	Lower looper thread guide set (No. 7.8.9 included)	
—	12	21	Lower looper supporter set (No. 1.2.3.4.5.6.7.8.9.10.11.12.13.14.15.16.17.18 included)	

13. Electronic parts




JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
40239465	13	1	Motor (100V)	JP
40233711	13	1	Motor (115V)	UL
40131419	13	1	Motor (230V/ 50Hz/ 90W)	CE/CH
40131421	13	2	Timing belt pulley	
40131422	13	3	Timing belt pulley cover	
-	13	4	Motor supporter	
-	13	5	Switch supporter	
40233664	13	6	LED PCB set (220~240V)	CE/CH
40233665	13	6	LED PCB set (100~120V)	UL/JP
-	13	7	LED PCB holder (A)	
-	13	8	LED PCB holder (B)	
-	13	9	LED cover	
40233715	13	10	Timing belt	
40233716	13	11	Machine socket	
40169427	13	12	Foot controller (100V) Japan	JP
40131437	13	12	Foot controller (115V) U.S.A.	UL
40131442	13	12	Foot controller (230V) Europe	CE/CH
-	13	13	Cord clip	
-	13	14	C4 End terminal	
-	13	15	Terminal w/transparent insulation tube	
-	13	16	Terminal w/un-transparent insulation tube	
40233717	13	17	Switch	
-	13	18	Washer	
40233718	13	19	Condenser (220V~240V)	CE/CH
-	13	20	E ring	
-	13	21	Nut (100~120V*3 PCS / 220~240V*5 PCS)	
-	13	22	Set screw	
-	13	23	Set screw	
-	13	24	Nut (100V~120V)	UL/JP
-	13	25	Set screw	
-	13	26	Set screw	
-	13	27	Set screw (220V~240V)	CE/CH
-	13	28	Set screw	
-	13	29	Set screw	
-	13	30	Washer	
-	13	31	Washer	

Rev01


Rev03

14. Accessories



JUKI品番 JUKI parts No.	分類 Class	No	品名(英) parts name	仕向地別 by specification
40233719	14	1	2-thread converter	
—	14	2	Brush	
—	14	3	Needle threader	
—	14	4	Screw driver	
—	14	5	Tweezers	
40131460	14	6	Needle set (#14 × 3)	
40137381	14	6	Needle set (#12 × 3)	
—	14	7	Spool holder	
—	14	8	Dust cover	
—	14	9	Chip box	
—	14	10	Flat blade screw driver	
—	14	11	Anti-spill net	
40233720	14	12	Upper cutter	
—	14	13	Thread unwinding spool cap	
40233721	14	14	Thread tension spring	
—	14	15	Accessory bag	
—	14	16	Accessory bag set (No. 10.11.12.13.14.15 included)	

15. Optional accessories



JUKI品番 JUKI parts No.		分類 Class	No	品名(英) parts name	仕向地別 by specification
Rev02 Rev02 Rev02 Rev02 Rev02	40233732	15	1	6 pcs optional feet set (With English manual)	
	40233726	15	2	Elastic foot set (With adjustable guide and English manual)	
	40131946	15	3	Blindhem & lace foot set (With English manual)	
	40131949	15	4	Beading foot set (With English manual)	
	40131950	15	5	Piping foot set (With English manual)	
	40131951	15	6	Taping foot set (With English manual)	
	40131948	15	7	Shirring foot set (With English manual)	
	40233733	15	8	Extension table set	
	40232011	15	9	Instruction manual 6 languages Europe	CE
	40232012	15	9	Instruction manual Japan	JP
	40232013	15	9	Instruction manual China (CS/CT)	CH
	40232014	15	9	Instruction manual 3 languages America	UL
	40233722	15	10	Color carton	CE/CH/UL
	40233723	15	10	Outer carton	CH
	40233724	15	10	Carton case Japan	JP
	40233725	15	11	Instruction DVD Japan	JP