

Winter Holiday



St. Moritz 2008

4D Family portrait scrapbooking "WINTER HOLIDAY"

Creating a scrapbook with embroideries is so much fun! – make your embroidery from your holiday photos and add creative taglines and a decorative frame using the great features in 4D Family Portrait. Use colorful fabric and use the appliqué function to make it look creative! Create your albums page by page easily!

(Intermediate skill level)

Sewing supplies

- PFAFF® Embroidery and sewing machine
- Scrapbooking Album w. post-bound (we have used size 20,5 cm x 20,5 cm (8"x8"))
- Cover fabric 70x50 cm (28"x 20")
- Appliqué fabric 16x12 cm (7"x 5")
- Sewing thread
- Robison Anton Rayon Embroidery thread
- Bobbin thread
- Inspira 90 Embroidery needle
- Tear away stabilizer
- Fusible fleece
- Pictogram Pen
- Pfiffikus
- 45mm Deluxe Rotary Cutter
- Quilt ruler
- Cutting mat
- Embroidery scissors
- Appliqué scissors
- Double sided tape

PFAFF® Accessories

- PFAFF® hoop closest to your scrapbook album size
- Hoop Magic

You can find these and many other accessories in the PFAFF® Accessory User's Guide or on our website www.pfaff.com, for purchase at your nearest PFAFF® Dealer.

Cut:

Include ¼" (6 mm) seam allowance.

- Cover pieces 4 piece 33 x 24 cm (13" x 9 ½")

EMBROIDERY

- 1) Take apart your album by loosen the small screws inside the fold of the cover. Place the cover on the wrong side of your fabric Trace with a Pictogram pen around the cover – repeat four times. Cut with seam allowance.
- 2) Hoop your front cover fabric with tear-away stabilizer and Hoop Magic. Make sure you tighten the fabric in the hoop. Thread your embroidery machine with embroidery thread in the top and bobbin thread in the bobbin. Always start with a new needle when you embroider your 4D PortraitStitch embroideries.
- 3) Select "Winter Holiday.vp3" and start the embroidery. Remember that this is appliqué embroidery so follow the instructions on your screen. Make sure you use good tools such as appliqué scissors when you work. When the embroidery is finished tear away the stabilizer.

Note: deselect the cut jump stitch feature and cut the threads manually with an embroidery scissors – this will make the stitch out faster due to the amount of jump stitches in the design. Make sure you cut the jump stitches at every color change.

Assembly instructions

- 4) Place the front cover right sides together with the back piece. Pin and stitch – leave an opening on the left side to slide the album cover into. Press before you assemble the album cover.
- 5) Turn the covers inside out. Clean cut corners. Press. Slide the album page into the opening on the cover. Do the same to the back page cover.

- 6) Fold and if necessary stitch or glue the edge opening. Reassembly the scrapbook album with plastic pages and screws. If you want to cover the rough edge you may glue a satin ribbon on the edge of the cover. Fold the album.



QUICK STEP SCRAPPING "BOBBY & LINDA"

- 1) Bobby is embroidered as an appliqué on solid fabric. Linda is stitched out directly on the background fabric. Make sure you have enough fabric to cover the cardboard paper which you will use when you are assemble your scrapbook page.
- 2) Press fusible fleece to get a softer touch to the page and also a bit more volume to the design.
- 3) Always hoop with Hoop Magic and start with a new needle size 90. The amount of stitches in this design is approx. 50,000 stitches. You should change the needle after half the embroidery has stitched out to stay out of needle trouble.
- 4) With this "Bobby" design we have worked with the frames and fonts that comes with the 4D Family Portrait program. Using colors in frames and fonts that match with the colors in the 4D PortraitStitch gives a very nice finish to your embroidery.
- 5) Do not over do it. Remember it is the 4D PortraitStitch out that should be in focus. Add details that match with the stitch out.
- 6) Mount the fabric on cardboard paper with double sided tape. Make sure the card board paper is not bigger then 29 cm x 29 cm (11"x11"), or approx. 1 cm (1/2") smaller then the plastic pocket. Place a piece of paper on the backside to cover the rough edges of the fabric.